

INSTRUCTIONS:

1. Remove old aerator from faucet. Use wrench if necessary place cloth over aerator to prevent damage.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads outside the faucet spout.
4. Place the new aerator insert into the original housing.
5. For housing with outside threads, use thicker washer. For housings with inside threads, use thinner washers. Install onto spout by hand.
6. Turn on faucet. If leak occurs, tighten more firmly.

INSTRUCCIONES:

1. Quite el viejo aireador del grifo. Si se necesita una llave inglesa, coloque un trapo sobre el aireador para evitar daños.
2. Quite todas las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas del grifo para una instalación más fácil.
4. Coloque el nuevo inserto de aireador dentro del estuche original.
5. Para estuches con roscas externas, utilice la arandela más gruesa. Para estuches con roscas internas, utilice la arandela más fina. Instale en el surtidor de agua en forma manual.
6. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.